

# VA-TOOL-KNIPEX-CMT-FLT

V1.2



KNIPEX tool is designed for industrial cameras to help with removal and installation of glass / IR Filters that are mounted inside the cameras. Color models feature an IR filter with a cut-off frequency of 700nm, while mono models have transparent glass windows.

**!! The removal of these filters is on your own risk and will void your camera warranty !!**

The KNIPEX tool, VA-TOOL-KNIPEX-CMT-FLT, helps you remove the glass window yourself at your own risk. This can also help with mounting the C-Mount Filter inside the C-mount camera.



## Steps to follow for C- Mount Filter

1. Use the KnipeX tool to extract the IR Filter / glass. This is essential for applications requiring different filters / lenses. (Note: without removal, C-Mount filters cannot be securely installed, and focus may be hindered).



2. Apply the C-Mount Filter.



3. Use the 1mm ring when installing the lens and secure it using the tool. (The 1mm ring is always delivered with the C-Mount Filters).



4. Ensure the lens can screw in fully and focus correctly.

The information provided in this documentation contains general descriptions and/or technical characteristics of the performance of the products contained herein. This documentation is not intended as a substituted for and is not to be used for determining suitability or reliability of these products for specific user applications. It is the duty of any such user or integrator to perform the appropriate and complete risk analysis, evaluation, and testing of the products with respect to the relevant specific application or use thereof. Neither VA Imaging nor any of its affiliates or subsidiaries shall be responsible or liable for misuse of the information contained herein or incorrect information in this document.